



TimeMizer™/MC

Spray System

Dilutes and dispenses degreasers and sanitizers for efficient cleaning and sanitizing of food contact surfaces.

Accurate

- Incorporates eductor, spray tools and metering tips which provide consistent, accurate dilution rates
- Achieves regulatory compliance when installed with proper equipment
- Uses J-Fill® Spill-Tite™/MC cartridges that are leak proof and virtually eliminates chemical exposure, tampering and manually diluting products
- Metering tip in each J-Fill® cartridge ensures precise dilution and eliminates possibility of tampering with dilution ratios
- J-Fill® dispensers use superconcentrated and Hyperconcentrated chemicals, reducing in-use cost, packaging used and solid waste disposal

Easy-to-Use

- Color-coded caps, buttons and hoses

Reduces Workplace Hazards

- Closed top minimizes opportunity for worker contact with concentrates

Rugged Construction

- Durable stainless steel cabinet is easily cleaned

Inconspicuous

- Cabinet is small and matches the decor of almost any food preparation area





Description of Features

TimeMizer™/MC Spray System is economical, accurate and promotes worker safety. It incorporates exclusive eductor, spray tools and metering tips which provide consistent, accurate dilution rates that help you achieve regulatory compliance. The chemicals used are packaged in Solutions Center® cartridges or Hanging Bags.

- Eductor and dispensing tools ensure accurate dilutions.
- Stainless steel cabinet construction. Cabinet dimensions are 9 inches by 11 inches.
- All water contact components are made with materials that are approved for potable water.
- For use with degreaser and sanitizer products.
- Dispenses up to 6 gallons per minute.

Technical data	TimeMizer™/MC
Operating Range Requirements	Water Pressure: 40–85 PSI (275–500 kPa) Water Flow: > 2.0 gal. / min. (7.6 L / min.) Water Temperature: 35–120° F (2–50°C)

Product	Description	Product code	
TimeMizer™/MC	Spray System Dispenser – For Hanging Bag Packaging	04352	
TimeMizer™/MC	J-Fill® Spray System	100863409	

Safe handling

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use; and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDS are available online at www.diversey.com or by calling 888.352.2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate.